Seats, Heated Rear, (4A4),(9AQ),(Q2J)

From January 2011



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Wiring Diagram

## E265 ( E128 ₽T20a T20a /17 0.5 1.5 sw/gn gn T2Id 0.35 2.5 br/ws br/ws sw/ws rt/ws ₩SF11 ST<sub>1</sub> G94 Z10 392 0.5 gn/br rt/ws 0.35 mmercial purposes, in part or in whole, is ner rotected by copyright. Copying for private or 394 with respect to the correctness of information in this document. Copyright by AUDI AG. 10 11 12 13 or [4GH-147020420] rs

## Left Rear Heated Seat Temperature Sensor, Left Rear Bench Seat Heating Element

- E128 Left Rear Heated Seat Regulating Switch
- E265 Rear A/C Display Control Head
- 594 Left Rear Heated Seat Temperature Sensor
- ST1 Fuse Panel 1
- SF11 Fuse 11 (On Fuse Panel F)
- T2ld 2-Pin Connector, In the Left Rear Seat
- T3r 3-Pin Connector
- T6t 6-Pin Connector, In the Coupling Point for the Left Rear Seat
- T20a 20-Pin Connector
- Z10 Left Rear Bench Seat Heating Element
- Z11 Left Rear Backrest Heating Element
- (392) Ground Connection 27 (in Main Wiring Harness)
- 394 Ground Connection 29 (in Main Wiring Harness)
- \* Climate Control, Comfort Climatronic
- \*2 For Vehicles Without Adjustable Seats
- \*3 Refer to Applicable Wiring Diagram for Fuse Positions
- \*4 Depending on Equipment
- \*5 Through May 2014
- \*6 From June 2014

= white = black = red = red = brown

green

= grey = lilac = lilac = yellow

= orange

= pink

= blue

## E265 ( E129 **€**<sub>T20a</sub> 0.5 1.5 1.5 \*2 1.5 \*2 rt/ws br/ws br/ws sw/ws 371 375 Z<sub>13</sub> G95 Z12 0.5 gn/br br/bl rt/ws 377 1.5 \*4 4.0 0.35 \*2 1.5 26 (34) (688) 21 22 23 25 27 [4GH-147030420]

## Right Rear Heated Seat Temperature Sensor, Right Rear Bench Seat Heating Element

- E129 Right Rear Heated Seat Regulating Switch
- E265 Rear A/C Display Control Head
- Right Rear Heated Seat Temperature Sensor
- 2-Pin Connector, In the Right Rear Seat
- 3-Pin Connector
- 6-Pin Connector, In the Coupling Point for the Right Rear Seat
- T20a 20-Pin Connector
- Z12 Right Rear Bench Seat Heating Element
- Right Rear Backrest Heating Element
- Ground Connection Under Driver Seat
- Ground Connection 6 (in Main Wiring Harness)
- Ground Connection 10 (in Main Wiring Harness)
- Ground Connection 12 (in Main Wiring Harness)
- Ground Connection 29 (in Main Wiring Harness)
- Ground Connection 2 on Center Tunnel
  - For Vehicles Without Adjustable Seats
- Depending on Equipment
- Through May 2014

= white

= black

= brown = green

= blue = grey = lilac

= lilac = yellow

= pink

rs

= orange

Through may 2014
Octivities or connected purposes, in part or in whole, is not of the connected purposes. In part or in whole, is not of the connected purposes. In part or in whole, is not of purposes. Protected by copyright. Copying permitted unless authorised by with respect to the correctness of information in this document. Copyright by AUDI AG.